



4. Adjust signal switch hub to 1/8 inch clearance with bottom of steering wheel and tighten wedge screw.

Pull signal switch wires tight at steering column wire slot opening and reinstall wire clamp with screw to steering column.