



6. Mount flasher wiring harness and complete the under cowl installation and connections making sure the colors are matched at the multiple connectors. Clamp signal wire harness to main harness about three inches from grommet.

7. Remove wiring harness grommet from dash panel and rework grommet enlarging hole.

Set direction signal harness in place and reinstall grommet.